

This Page Is Inserted by IFW Operations  
and is not a part of the Official Record

## **BEST AVAILABLE IMAGES**

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images may include (but are not limited to):

- BLACK BORDERS
- TEXT CUT OFF AT TOP, BOTTOM OR SIDES
- FADED TEXT
- ILLEGIBLE TEXT
- SKEWED/SLANTED IMAGES
- COLORED PHOTOS
- BLACK OR VERY BLACK AND WHITE DARK PHOTOS
- GRAY SCALE DOCUMENTS

**IMAGES ARE BEST AVAILABLE COPY.**

**As rescanning documents *will not* correct images,  
please do not report the images to the  
Image Problem Mailbox.**

**Figure 1**

- 1- Streaming Source
- 2- Source's Web Server
- 3- Internet
- 4- Application Web Server
- 5- Internet
- 6- Internet Service Provider
- 7- Consumer's Computer

8- Proprietary Y Adapter Cable

9- Computer's Speakers

10- Free Standing Wireless Transmitter

11- Wireless Receiver For Audio

12- Free Standing Wireless Receiver For Video

13- Television

14- Stereo Amplifier

15- Stereo Speakers




Figure 2




Figure 3




Figure 4





Figure 5



**Figure 6**




Figure 7







Figure 8

# Proprietary Y Adapter Cable

- 1- Stereo Mini Plug (Audio)
- 2- Five Inch Positive Wire, Left Audio Channel
- 3- Five Inch Ground Wire
- 4- Five Inch Positive Wire, Right Audio Channel
- 5- Encasement of the Above Wires
- 6- Stereo Mini Jack (Audio)
- 7- Six Foot Cable, Left Audio Channel, Positive Wire
- 8- Six Foot Cable, Left Audio Channel, Ground Wire
- 9- Six Foot Cable, Right Audio Channel, Positive Wire
- 10- Six Foot Cable, Right Audio Channel, Ground Wire
- 11- Mono Phono Plug, Left Audio Channel
- 12- Mono Phono Plug, Right Audio Channel
- 13- S-Video Plug For Video  
OR
- 14- Mono Phono Plug For Video
- 15- Six Foot Cable, Positive Wire For Video
- 16- Six Foot Cable, Ground Wire For Video
- 17- Encasement For Above Wires
- 18- Mono Phono Plug For Video



1- Login Page

2-Main Page  
Administration Panel

2a-Add a New Station

2b-List All Stations

1. Delete

2. Activate

3. Inactivate

2c- Add New Country

2d-Add New State

2e- Add New Province

2f- Add New Banner

2g- List All Banners

1. Delete

2. Activate


3. Inactivate

4. Show the banner

2h- Configuration/  
Preferences Page

2i- Modify Admin Info

3- Database



# Internet Application (Front End)

Figure 10

1- Intro Page

2-Main Page

3- Advanced Search  
Link

4-Advanced Search  
Page

5- Basic Search DB  
Connection

6-Advanced Search  
DB connection

7- Database

8- Database- Search  
result output page  
connection (for basic  
'search and  
advanced search)

9- Results Pages.

10- Output page DB  
connection

11- Output page  
Player Connection

12- DB player  
connection

13- Player Page

14- My Favorites  
Page

15- External page  
(station's page)

